

尺寸:95x140mm(成品) 285x140mm(展开) 颜色:K
 材质:70克书纸 工艺:风琴折页做压痕,单色印刷

NexTool


纳拓户外烹饪套装使用说明书

使用产品前请仔细阅读本说明书,并妥善保管

产品结构

套装内含


收纳包




三德刀

磨刀器

刀套




多功能剪刀




工具操作


收纳包打开形态




快捷磨刀



可拆卸单独使用



多功能烧烤夹



筷子




勺子



铲子



拆装说明



产品参数

套装组件	产品主材	表面处理	涂料材质	产品尺寸(mm)
收纳包	尼龙	-	-	300×135×60(折叠) 435×376(打开)
三德刀 (食品接触用)	PP, 30Cr13	喷食品级特氟龙(有机硅不粘涂料)	聚四氟乙烯	267.3×19×37.3 (不含刀套)
多功能剪刀 (食品接触用)	PP, 30Cr13	镀黑钛	钛或含钛化合物	226 × 79.5 × 14
烧烤夹 (食品接触用)	301(12Cr17Ni7)	喷食品级特氟龙(有机硅不粘涂料)	聚四氟乙烯	250 × 60 × 20
筷子 (食品接触用)	304(06Cr19Ni10)	镀黑钛	钛或含钛化合物	230 × 6 × 6
勺子 (食品接触用)	硅胶, 尼龙	火花纹	-	273 × 57 × 17.3
铲子 (食品接触用)	硅胶, 尼龙	火花纹	-	275 × 56 × 16.9

产品保养

1. 使用完应注意清洁,特别是将盐渍、油脂、污垢等彻底洗净,并且确保无碎纸片或粉尘堵塞,并且擦干收纳。
2. 必要时可适当用润滑脂等涂擦,以确保使用顺畅,防止生锈。
3. 产品能胜任日常活动的正常使用,但是也应避免非必要的超负荷暴力使用,以防变形或损坏。

NexTool


User Manual of Nextool Outdoor Cooking Set

Please read this manual before using and keep it carefully

STRUCTURE


Included in the set

Organizer bag




Santoku Knife

Knife sharpener Sheath




Multifunction Scissors




Tool operation


Organizer bag design




Quick Sharpening



Disassembled for individual use



BBQ Tongs



Chopsticks




Spoons



Spatula



Disassembly instructions



SPECIFICATIONS

Package Components	Main Materials	Surface Finishing	Coating Materials	Size(mm)
Organizer bag	Nylon	-	-	300×135×60(Folding) 435×376(Show)
Santoku Knife	PP, 30Cr13	Food grade Teflon coating (silicone non-stick coating)	PTFE	267.3×19×37.3 (Without knife sheath)
Multifunction Scissors	PP, 30Cr13	Black titanium coating	Titanium or Titanium compound	226 × 79.5 × 14
BBQ Tongs	301(12Cr17Ni7)	Food grade Teflon coating (silicone non-stick coating)	PTFE	250 × 60 × 20
Chopsticks	304(06Cr19Ni10)	Black titanium coating	Titanium or Titanium compound	230 × 6 × 6
Spoons	Silica, Nylon	Sparkle pattern	-	273 × 57 × 17.3
Spatula	Silica, Nylon	Sparkle pattern	-	275 × 56 × 16.9

MAINTENANCE

1. Clean after use, especially wash off salt, grease, dirt, etc. thoroughly, and make sure there is no shredded paper or dust clogging, and dry it for storage.
2. If necessary, it can be properly coated with grease, etc. to ensure smooth use and prevent rust.
3. The product is capable of normal use in daily activities, but should avoid non-essential overloading and violent use to prevent deformation or damage.