

# 发光模式 暖白低亮 暖白高亮 暖白呼吸灯 红光闪烁 亮 度 运行时间 充电时间 跌落高度 产品重量 282g±5g(净重,不含蚊香液) 产品尺寸 ∅96.4×128.3mm 内置电池 204040锂聚合物电池, 3600mAh 3.6V 12.96Wh 额定输入 定时档位 一档2h、二档4h、三档8h 驱蚊范围 35㎡ (室内) 电热器工作温度 110 ± 7°C 氯氟醚菊酯含量 0.6%±0.09% **配 件** 主机×1、手提带×1、驱蚊液×3、说明书×1、充电线×1



# 1. 先取出包装内所含的配件,按下图指引旋 转打开盖子。



# 2. 打开盖子后,将驱蚊液如图所示安装,旋转 拧紧后,放入产品底部并拧紧,即可使用。



## 灯光操作

单击驱蚊档位键。开启 2h 定时驱蚊模式,对 连续单击灯光按键,可循环切换,暖白低亮 应指示灯点亮; 2h 计时结束时指示灯熄灭, →暖白高亮→暖白呼吸灯→红光闪烁→灯 内置风扇延时5分钟停止工作。(第二、三次 光关闭。 单击时,同理4h、8h计时结束时指示灯熄灭, 四秒内单击切换模式,点亮超过四秒再单击 内置风扇延时5分钟停止工作) 开关直接关闭。 第四次单击,关闭驱蚊模式,内置风扇延时

5分钟停止工作。(风扇延时关闭,是为了把注意:当电量过低时,红色指示灯闪烁提醒, 插上充电线充电时,红色指示灯长亮(正在 充电),电池充满后绿色指示灯长亮,拔掉充 电线,电量指示灯熄灭。



# 注意事项(请仔细阅读并严格遵守)

- 1. 产品只能使用推荐的蒸发介质,使用其他介质可能会产生毒性或发生火灾。
- 2. 使用时, 请打开门窗, 在驱蚊过程中可让蚊虫逃离室内, 驱蚊结束后再将门窗关闭。
- 3. 使用时请勿触及器具挥发介质的热表面。
- 4. 请勿使用输出为 5V---2A 外的电源,可能导致发热或故障,严重时可能会引发火灾。
- 5. 请将产品放置于平稳处,避免产品跌落,导致故障和损坏。
- 6. 使用本产品灭蚊时, 需提前开启(>3小时), 切勿睡觉时才开启使用。
- 7. 无人环境下使用效果更好,避免因人体温、气味干扰蚊虫,影响使用效果。
- 8. 请勿在产品故障状态下使用。
- 9. 儿童、老人应在监护和指导下使用。
- 10. 请勿私自拆卸零件,可能会导致产品故障或损坏。
- 11. 本产品须由本公司认可的单位或技术人员进行更换及维修。

### 电池环保处理

在废弃器具前,必须将电池从产品中取出。产品断电,砸烂灯罩,取出电池安全地处理。

本保修政策是制造厂商("我们")向最终用户("您")提供保修和其他相关事宜的法律文件,请您妥善保存。如您在购买产 品时销售商或其他第三方声明将由其提供保修服务或其他更多服务的,则保修服务或 其他服务将由销售商或第三方提

本學修服多仅适用于符合出厂配置的产品或其部件在保修期内经正常使用时出现保修范围内的性能故障。保修范围内

保修期自产品交付之日起算一年。网络、电话或其他非现场交易的交付日以第三方物流记载的交付时间为交付日;其他

情形则以发票日为交付日,但如您确能有效证明非因您的原因导致发票日早于实际交付日的,经我们确认无异议后可以 实际交付日为准。如您无法提供有效的第三方物流交付信息或发票的,则保修日自产品出厂后三十日起算。具体保修期

申请保修时,您应提供清晰,完整和准确的①产品发票;②保修卡;③电商平台订单信息(如有);如因您无法提供而不能

1.自保修期起始后 7 日内,产品出现性能故障,经由我们或我们授权的售后服务中心检测确定,可免费享受退货或换货

3.自保修期起始后12个月内,产品出现性能故障,经由我们或我们授权的售后服务中心检测确定,可免费享受维修或更

换服务。维修或更换的产品将在原产品在剩余保修期内继续享有保修服务,剩余保修服务期不足3个月的,则剩余保修

#RXEL3 1 73。 4.退货或换货时,您需将产品随附物及包装一并完整退还,并保持产品本身、附随配件、产品外观不存在任何破损、划伤、

5.属于保修范围内的产品硬件故障,由我们承担物流费用和保修产生的其他费用。经确认不属于保修范围内的故障或损

自保修期起始后8-15日内,产品出现性能故障,经由我们或我们授权的售后服务中心检测确定,可免费享受换货或维

性能故障的界定, 如国家有相关规定的, 依据国家规定; 如无规定, 将由我们依据本保修政策判定。

. 部件有明显的硬物损伤,伤痕、缺角、严重变形、破损等现象;

产品使用过程中发生的脱色、磨损和消耗

t于超出保修期或保修服务范围之外的产品故障, 经确认可由我们提供服务的, 我们将提供有偿的专业维修服务, 您知 悉并同意维修时旧部件将被回收。除非届时另有明确约定,我们将对被维修或更换的零部件提供90天的质保期。

随产品或部件的相关标签、标识被更改或去除,如:保修凭证上产品信息或序列号与实物不相符合,或有涂改的;

x服务政策适用中国大陆区域的法律(不包括其冲突法)。 如因本文件项下的事官发生任何争议,友好协商未果的,将提交阳江市江城区有管辖权的人民法院裁决。)

### 保修卡

产品信息	品名	型 号	
用户信息	姓 名	电 话	
	地 址		
销售商信息	名 称	电 话	
	地址/网址		
	销售日期	发票号码	

如有售后服务需求,请联系广东百创源科技股份 有限公司客服部门

售后服务电话: 0662 - 369 2722


服务时间:周一至周日 8:00 - 17:15

制造商·广东百创源科技股份有限公司 地址: 广东省阳江市江城银岭科技产业园B9-3

纳拓小白驱蚊营灯使用说明书

使用产品前请仔细阅读本说明书,并妥善保管

### Light pattern Red light flash 120lm Run time 60h Charing time Around 5.5h Drop height Product weight 282a + 5a (Net weight, do not contain liquid mosquito repellent incense Product Size Ø96.4 × 128.3mm Lithium polymer battery, 3600mAh 3.6V 12.96Wh 5V===2A Regular Time First gear 2h, second gear 4h, third gear 8h 35m² (Indoor) Temperature 0.6%+0.09% permethrin conten Main lamp×1, Carry-on strap×1, Mosquito repellent×3, User manual×1, Accessories Charging cable x 1




### First take out the accessories contained in the package, and then open the lid by rotating according to the above instructions.

Installation







# Mosquito repellent button operation | Lighting operation

灯内已挥发蚊香液吹散)

2 hours after the timer mosquito repellent mode, circularly. Warm white Low light → Warm White the corresponding indicator light on; 2h When Highlight → Warm white breath light → Red the timer ends, the indicator is off, and the fan light flash → Lights off. stops working five minutes later. (For the Click to switch mode in four seconds. Lights second or third click, the indicator will be off at on after four seconds, click to turn off. the end of 4h or 8h, and the fan will delay fo 5 minutes to stop working.)

Click the fourth time to disable the mosquito light will flash to remind you. When you plug in repellent mode, and the fan stops working five the charging cable, the red indicator light will minutes later.(The fan is turned off on delay be long On (the battery is being charged), the to blow out the volatile mosquito repellent areen indicator light keeps on after the battery inside the lamp)



cable is remove

Note: when the power is too low the red indicator.

is full, and the light goes out after the charging

or fire Click the mosquito repellent gear keyboard. Click the light button continuously to switch 2. Please open the door or window to allow the mosquitoes to escape during the process, and lock the door or window when the repellent is finished.

3. Unconsciously use without touching the thermal surface of the device's volatile media.

NOTES (PLEASE READ CAREFULLY AND STRICTLY ABIDE BY)

1. Lent only uses the recommended volatile media, as using something else can cause toxicity

4. Anyway, don't use a power source whose output is outside the 5V == 2A, which can cause heating or failure, or in serious cases, a fire.

5. Please placing it in a smooth place to prevent it from dropping, otherwise can lead to faults and damage. 6. To use the product to kill mosquitoes, you spend time on the front screen (> 3 hours), instead

- of using it while sleeping. 7. No one inside the room it will works better, avoiding interference with mosquitoes due to human
- body temperature and smell, which can affect the using effect.
- 8. Do not use it while it was fault.
- 9. Children and the elderly spend time at the front of the house, paying for their own education. Unconsciously, do not disassemble parts, which may cause fault or damage to the product. 10. The product is replaced and repaired by a company approved provider or technician.

# BATTERY ENVIRONMENTAL TREATMENT

Before discarding the appliance, the battery must be removed from the product. Power off the product, smash the lampshade, remove the battery and dispose of it safely

1.因误用、意外、改装、私拆、进液等不适当的物理或操作环境、不可抗力、不当维护或保管导致的故障或损坏;

This warranty pointy is a flegal occurrent we industried in the florid or other toles, supposing warranty only in a flegal occurrent we manufactured provide or other third party whom you but yit the product from declares that it will provide warranty service or other more services, the warranty service or other services will be provided by the retailer or third party.

varranty service is only applicable to the product or its parts that meet the factory configurations during normal mis warranty service is only appricate to the processor and the extreme the raciny configurations. The definition of performance failure within the warranty period when there is a performance failure within the warranty scope. If the country has relevant regulations, shall be based on national regulations, if there are no regulations, we will determine it in accordance with this warranty policy.

### 2. Warranty period

限和其他事官,请同步贝保修卡。

A. 致电: 0662 - 369 2722;

您可以按照如下方式联系我们以获取保修服务:

确认产品来源的, 您将无法获取保修服务。

服务。换货的,保修期将重新计算。

修昭冬, 雄货的, 保修期终重新计管,

损坏;维修的,维修时新换上的部件归属于您,旧件将被我们回收。

坏的,除非届时另有规定,由您承担往返运费(如有)和运输过程中的风险。

old days after the product leaves the factory. Please see the warranty card for the specific warranty period and other

3. How to access to our services Below optional methods for you to contact us for warranty service: A. Service hot-line: 86 - 662 - 369 2722

ntact the selling platform where you buy the product.

warranty application, please submit clear, complete and correct documents including ① invoice;② warranty card you cannot provide above proofs indicating the source of the product, you will not be able to obtain warranty service.

or our authorized after-sales service center, you can enjoy the return or replacement service for free. For segment product the warranty period will be recalculated Within 8-15 days since the start of the warranty period, if the product has a performance enjoy failure, and it is nfirmed by us or our authorized after-sales service center, you can free replacement or repair services. For placement product, the warranty period will be recalculated.

eplacement product, the warranty period will be recalculated, yithin 12 months sone the start of the warranty period, the product has a performance failure, and it is confirmed yithin 12 months sone the start of the warranty period, of the first product has a performance failure, and it is confirmed period, the product or product with replaced components will continue to enjoy the warranty service during the remaining the original product. If the remaining warranty service period is less than 3 months when warranty period the repair

component replacement occurs, the remaining warranty period will be extended to 3 months.

When return or replacement is required, the product should be in original condition in complete packaging. The main odduct itself as well as all the accessories should be without any damage, scratches or breakage. For repairs, new

propropered become part of your condent and the components or passed the utility and the return of the part of the

Non-warrany coverage
 — Non-warrany coverage
 — Replace to applicable under following occasions:
 - Failures or damages due applicable under following occasions:
 – Failures or damages due susued by improper physical or operating environment, force majeure, improper maintenance storage, such assembles assumed to the storage of the storage

The relevant labels and marks of the products or parts are changed or removed, such as: the product information or ial number on the warranty certificate does not match the actual product, or has been altered, Components with obvious damages by hard objects, scratching marks, broken corners, severe deformations and other breakages. 6). Warranty period expires.

6. Paid services or product failures beyond the warranty period or outside the scope of the warranty service, we will provide paid rofessional repair services if it is confirmed within our service scope. With your knowledge and agreement, the old omponents replaced will be recycled when repaired. Unless expressly agreed otherwise, we will provide a 90-day

his service policy applies to the laws of mainland China (excluding its conflict laws). If any dispute arises due to the natters under this document and the friendly negotiation fails, it will be submitted to the People's Court with risdiction in Jianqcheng District, Yangjiang City for ruling.

### WARRANTY CARD

	Description	Ivallie	Woden	
	User	Name	Phone	
	Information	Address		
		Address	Phone	
	Retailer Information	Address/Website		
		Sale date	Invoice#	

For after-sales service needs, please contact the customer service department After-sales service phone: 86 - 662 - 369 2722



